



AEROGAM

AUTHENTIC KITCHEN EQUIPMENT

NEUTRAL ELEMENT

INFORMATION MANUAL



INFORMATION MANUAL
EN_AEROGAM_NEUTRAL ELEMENT_REV. A
First release by ECE on 02/10/2019
Last revision by ECE on 02/10/2019

APPLIES TO:				
V01384	V02466	V01383	V02447	V02467

CONTENT

INTRODUCTION	1
1. FOREWORD	1
2. CONTACTS	1
3. WARRANTY	1
4. RESTRICTIONS OF USE	1
5. ABOUT EQUIPMENT DISPOSAL.	1
INSTALLATION	2
1. GENERAL INFORMATION	2
2. HANDLING	2
3. SPECIAL PRECAUTION AND LEVELLING	2
4. DATA PLATE	2
CLEANING & UPKEEP	2
1. WARNINGS	2
2. CLEAN THE STAINLESS-STEEL CASING	2

REVISION HISTORY

Revision n°	Revision author	Revision date	Revision content
A	ECE	02/10/2019	First release



INTRODUCTION

1. FOREWORD

We would like to thank you for choosing Charvet for your installation. Our equipment is designed and manufactured in France by our team, engaged at the pursuit of five main objectives: Robustness, Performance, Hygiene, Ergonomics and Safety.
If despite our commitment, you encounter a problem with one of our products, our after-sales service is at your disposal.

2. CONTACTS

For any information, or commercial request, please contact:

✉ info@charvet.fr

☎ +33 (0) 4 76 06 64 22

For any assistance request, please contact our after-sales service:

✉ sav@charvet-sa.fr

☎ +33 (0) 4 76 06 64 22

3. WARRANTY



INFORMATION

Our warranty is discussed in our sale contract. For any new installation or repair work on an equipment under warranty, please contact an authorized retailer. Furthermore, we would like to remind you that CHARVET's warranty does not cover any deterioration consecutive to a bad installation, utilization or servicing of the equipment. Please read this manual in its entirety before any operation.

4. RESTRICTIONS OF USE



INFORMATION

This equipment must be used by qualified people only. It is mandatory that the installer provides training to the final user of the equipment once the installation has ended. This training must lead to the delivery of the information manual of the equipment to the final user.
CHARVET would remind that its devices are not designed to be used by people with reduced physical, sensory, or intellectual abilities, unless they are under the supervision of person who is liable and can guarantee their safety.

5. ABOUT EQUIPMENT DISPOSAL.



INFORMATION

The equipment's packaging shall be treated and recycled according to local rules of disposal.

At the end of its life, the equipment shall be eliminated and recycled in accordance with the local rules.

INSTALLATION

1. GENERAL INFORMATION

The installation must be performed by a qualified installer. This one will install the equipment in compliance with the instruction provided in this manual and with local installation standards.

A special attention must be paid to the local rules concerning fire prevention.

2. HANDLING

For any handling operation, please let the equipment on its wooden plate until the equipment is at its final location. Upon receipt, unpack and check the equipment.



WARNING

In case any damage occurs during transportation of the equipment:

In case any damage has occurred during transportation, a claim must be sent to the carrier within 24 hours in written form by registered letter with acknowledgment of receipt. You should include every references / order numbers, and a copy of the delivery note.

3. SPECIAL PRECAUTION AND LEVELLING

It is mandatory that the equipment is levelled before any use. To set the level of the equipment, it is possible to set each foot (Or bolt for concrete base) individually.



Fig. 1

4. DATA PLATE

Each neutral equipment comes with a data plate. Its location depends on equipment configuration.




Fig. 2

CLEANING & UPKEEP

1. WARNINGS



WARNING

Before to process the cleaning of the equipment, please make sur that equipment's temperature is supportable, please equip yourself with suitable protection equipment if necessary.

Prefer to clean this equipment once it has been disconnected from its mains.

This equipment must not be cleaned with water jet, water steam, or pressured water.

Use of bleach or acids, even greatly diluted is absolutely forbidden.

2. CLEAN THE STAINLESS-STEEL CASING

The equipment will be performed using a wet sponge and soapy water (Or any other neuter detergent). In case of inlaid dirt, it is possible to use a scouring sponge taking care of rubbing the same direction than surface polishing (Otherwise, it may deteriorate the surface aspect). Finally, rinse with clear water, the dry each surface with an oily rag.